



Conduit shall come straight down from meter base with one sweeping 90 below grade pointing toward source.

If more than two(2) elbows are needed, consult FDEC before installing. All elbows are to be sweeping type.

When stubbing up conduit at the pole, keep the conduit 10 inches away from pole. Conduit should stub up at pole a minimum of 2 feet. Utility will run it up the pole.

When trenching & running conduit to a pad mount transformer, stop 2 feet away from transformer. Utility will run it into transformer.

NOTICE

Customer must notify utility before trench is covered. Utility needs to inspect trench and possibly add required communication conduits.

FORKED DEER ELECTRIC CO-OP			
SECONDARY URD SERVICE			
UNDERGROUND SERVICE			
DATE	REVISION	DATE	REVISION
.01/2/2010			